UPSI-1208DP2

12 V DC / 7 A

- 2 12 V DC UPS (DIN rail version)
- Maintenance-free supercap technology
- **Over the Second Of Second**
- Intelligent power sharing
- Regulated output voltage
- Min. load disconnect
- Power fail timer
- Reboot function
- Fuel gauge















Technical data	
Input voltage	12 VDC (11.516 V)
Input current	8.8 A max.
Output voltage	Normal mode: V _{in} – 0.3 V (Full load) Backup: 12 V DC
Output current	7 A continuous
Supercaps charge current nom.	Depending on load max. 10 A on Supercaps
Charging method	CC/CV/CP
Protection	Overcurrent protection Reverse polarity protection
Interface	USB, RS232, USB-HID
Type of energy storage	Supercaps 9V max.
Life cycles	> 500 000
Safety / EMC	CE, Class B (EN55032)
Temperature	Operating discharge: -20+65 °C Operating charge: -20+65 °C Storage: -20+65 °C, recommended 0+40 °C
Max. operation altitude	5000 m
Derating (depending on operation altitude)	2000 m operation altitude or higher: 5.7 W / 500 m or reduction of operation temperature of 3.5 °C / 500 m
Humidity	Operating: 1085 % RH, non-condensing / Storage: 1090 % RH, non-condensing
Dimensions (WxDxH)	63 x 100 x 120 mm ±0.5 mm
Weight (net)	0.62 kg


Product specific data	
Shutdown detection	Via load sensor
Reboot function	Reboot function and time can be configured by software
Load sensor	Configurable via UPSI HID-Battery-Parameter software (download at www.bicker.de) UPS shuts down after 15 sec, if connected load decreases below set value and UPS is being in battery mode
Timer function	Configurable via UPSI HID-Battery-Parameter software in steps of single seconds (3600 sec max)
Relay	Dry contact on power fail (Normal mode: open / Backup mode: closed) Relay switching current max 0.5 A @ 125 V A C / 1 A @ 24 V D C


Backup time depends on Supercap capacitance, load and temperature. At very high or low temperatures a reduction of backup time occurs.




Tolerance ±0.5 mm

Drawing UPSI-1208DP2








Status LED	Description
1 x flash, pause 1.5s	Status: Battery start
2 x flash, pause 1.5s	Status: Capacity for start is required, state charging
3 x flash, pause 1.5s	Status shutdown: Waiting for shutdown completion
4 x flash, pause 1.5s	Status reboot: Output is switched off and time runs until restart (Reboot)
5 x flash, pause 1.5s	Status: No battery recognized
1 Hz flash > power fail	Status: Backup mode
Always on	Status: System OK
Quick flashing	Critical Error Status: Output voltage too low > UPS will be shut down Status: Overcurrent detected > UPS output disabled



Backup time UPSI-1208DP2



Safety information



Specification is subject to change without notice. Errors excepted. Status as at: 17.09.2019

Please consider to each country's own regulation about recycling and disposal of used batteries etc. in hazardous waste or resending to any recycling organization. The battery pack should not be exposed to fire, immersed under water, soldered, opened, short-circuited, reversed or overheated. During storage the battery pack should not be exposed to temperatures outside the specification and should not be pushed too heavy and not exposed to high pressure. Do not swallow any parts of the battery pack.

Scope of delivery

Quantity	Description
1x	UPSI-1208DP2 - DC UPS
1x	V _{in} / V _{out} connector counterpart
1x	Relay connector counterpart

